



NOTES:

- 1). INSTALL SANDBAG DIKE IN UPSTREAM LOCATION FIRST.
- 2). CONSTRUCT SANDBAG DIKE SUCH THAT THE HEIGHT IS 1'-0" ABOVE THE PEAK ELEVATION OF THE 1 YEAR STORM, OR 1'-0" BELOW THE TOP OF THE BANK, WHICHEVER IS LESS. SEE PLANS FOR MORE INFORMATION.
- 3). CONSTRUCT WEIR SUCH THAT IT WILL PASS A 1 YEAR STORM EVENT PEAK FLOW. SEE PLANS FOR MORE INFORMATION.
- 4). SIZE THE PIPE SUCH THAT IT WILL ALLOW PASSAGE OF THE STREAM BASE FLOW.



DELAWARE
DEPARTMENT OF TRANSPORTATION

SANDBAG DIKE				APPROVED	SIGNATURE ON FILE	12/30/2014
					<small>CHIEF ENGINEER</small>	<small>DATE</small>
STANDARD NO.	E-15 (2014)	SHT.	1 OF 1	RECOMMENDED	SIGNATURE ON FILE	12/11/2014
					<small>DESIGN ENGINEER</small>	<small>DATE</small>