


SCALE : NTS



NOTES:

- 1). INVERTED CONFIGURATION SHALL BE USED FOR SPAN MOUNT.
- 2). SPAN WIRE MOUNTING HARDWARE SHALL BE SUPPLIED BY THE CONTRACTOR.
- 3). TEFLON TAPE SHALL BE APPLIED TO THREADS BEFORE MOUNTING.
- 4). ROUTE THE LEAD-IN CABLE THROUGH THE METAL CAP AND THE RUBBER PLUG. REPLACE THE METAL CAP, SEALING THE CABLE ENTRY PORT. TIGHTEN THE METAL CAP SO THE CABLE WILL NOT SLIDE THROUGH THE RUBBER PLUG.




 ENGINEERING SUPPORT DATE 09/01/2020
RECOMMENDED

EMERGENCY PREEMPTION RECEIVER - INVERTED MOUNT
 STANDARD NO. T-14 (2020) SHT. 2 OF 2

REVIEWED  DATE 09/01/2020
 DEPUTY DIRECTOR - DESIGN
 APPROVED  DATE 09/01/2020
 CHIEF ENGINEER